

ELECTRICAL USAGE GUIDE

The following wattages are approximate and are provided to help you estimate your power usage. We recommend that you refer to a specification sheet or the electrical stamp or label usually located on the back or bottom of any electrical apparatus and order one outlet for each piece of equipment to avoid tripping/power outages during the event.

100 WATTS = 1 AMP

WATTAGE		WATTAGE	
Blender	1000	Imprinter for T-Shirts	2000
Can Opener	500	Iron	700 - 1100
Credit Card Reader / Lead Retrieval	100	Juicer	
Cash Register	100 - 200	Single	500
Coffee Pot		Double	1000
Household size	1200	Laminator	2000
Large Brewer	1500 - 2000	Lead Retrieval / Card Reader	100
Computers		Lights with Freeman rental booths	200 each
Desk Top (monitor & CPU)	200 - 900	Microwave Oven	500 – 2000
Lap Top	150 - 300	Mixer	500 – 1000
Monitor (independent)	50 - 200	Photocopier	dependent upon size – may require 208v
Computer Printer		Pizza Oven (small)	30 amp/120 volt Special Connection
Dot Matrix	100 - 500	Plasma TV – 32” to 50”	1000
Laser	400 - 1000	Popcorn Maker	2000
Crock Pot	200 -1000	Projector (May be dependent upon size)	1000
DVD Player	100	Refrigerator	
Electric Frying Pan	1200 - 2000	Small	100
Fax Machine	1000	Regular	700
Food Processor	500 – 2000	Meat Slicer	500 - 1000
Glue Gun	300	Steamer	2000
Griddle	1500	Stereo (amplifier)	100 - 500
Hair Dryer	1000 - 1900	Television	100 - 500
Heat Lamps (per lamp)	250	Toaster	1000
Heater (portable)	1500 - 2000	Toaster Oven	1500
Hot Plate		Typewriter	100
Single	1000	Vacuum Cleaner	1500
Double	1500 – 2000	Water Cooler	100
Hot Water Heater	30 amp/208 volt/Single Phase		